



Quick Start

(SR06)



Please read all instructions before use for the best performance of this product. Save these instructions for future reference.

Box Contents



Bookshelf Speaker



Remote Control



Quick Start




RCA to RCA
audio cable



Stereo RCA to
3.5mm audio cable




Digital Optical cable



Power Adapter

LED Indicators and Button Introduction



Active Speaker

Infrared receiver

LED Indicators




RCA




Bluetooth



Optical



Active Speaker



Passive Speaker

01. Power switch

02. Input selection

Press in to navigate between audio sources: Bluetooth -> Optical -> RCA

03. Sound effects

Press in to navigate between audio sources: Music -> Dialogue -> Movie

04. Volume control

05. RCA input port

06. Optical input port

07. Left speaker audio output

08. Power port


09. Left speaker audio in

Know Your Remote



	Power button		Mute/Unmute
	Volume up		Volume down
	Previous track		Next track
	Play/pause		Increase or decrease treble
	Increase or decrease bass		Restore factory settings
	Movie mode		Music mode
	Dialogue mode		Bluetooth mode
	Optical mode		RCA mode


Connection Diagram



- a** Bluetooth
- b** Stereo RCA to 3.5mm audio cable (supplied)
- c** Digital Optical cable (supplied)
- d** RCA to RCA audio cable (supplied)
- e** Power Adapter (supplied)

Connecting with a TV

Active Speaker




- A** Method 1. Connecting using an Optical cable. Select Optical mode and set the TV's audio output to "PCM".
(More information on PCM page)
- B** Method 2. Connecting using a RCA to 3.5mm audio cable. Select RCA mode.

Setting "PCM" on your TV

When all cables are connected properly, and LED indicator lights properly, if there is no sound from tv or Soundbar, please setting your tv as below:

1. Press "Menu" on the TV's remote control.
2. Press the arrow keys on the remote to scroll to "Audio Settings."
3. Press "OK" on the remote control.
4. Scroll to "Advanced Audio" and press "OK". Some televisions may not have an "Advanced Audio" menu and may list various audio settings instead.
5. Scroll to "Audio Output Mode" or "Digital Audio Output Mode" and press "OK".
6. Scroll until "PCM" is displayed as the current audio output.
7. Press "OK" to save the settings.

Connecting a Bluetooth Device



- a. Press the "BT" button on the remote or press the "BT" button on back panel of the active speaker, the LED indicator blinks blue.
- b. Turn on Bluetooth on the Bluetooth device.
- c. Select "BESTISAN SR06" and connect it. When your Bluetooth device is connected, the LED indicator blinks blue slowly.
- d. Play music files from the device, connected via Bluetooth, through the bookshelf speaker.

Specifications

Power output:	L/R: 25W + 25W
Signal to noise ratio dB(A):	L/R: ≥85dB (A)
Input sensitivity:	LINE IN: R/L: 600±50mV
	OPT: R/L: 500±50mFFS
Frequency response:	45HZ-20KHZ
Bass unit:	4 inch (102mm)
Tweeter unit:	1.25 inch (32mm)

Troubleshooting

No sound

- Check if the power indicator light is ON.
- Try to turn up the volume using either the master volume control or remote control.
- Ensure the audio cables are firmly connected and the input is set correctly on the speakers.
- Check if there is signal output from the audio source.

Cannot connect via Bluetooth

- Make sure the speaker is switched to Bluetooth input, in other audio input mode Bluetooth can not be paired or connected. Disconnect from any Bluetooth device by press and hold the volume dial in Bluetooth mode, then try again.
- Effective Bluetooth transmission range is 10 meters, please make sure operation is within the range.
- Try another Bluetooth device for connection.

The SR06 Bookshelf Speaker does not turn on

- Check if mains power is connected. or if the wall outlet is switched on.

Thanks for reading!

Best Artisan Corp.

801 DUPONT AVE SUITE F & G, ONTARIO, CA, 91761.

service@bestisan.com